

Formes et mesures LANCASTER

TABLES DE CENTRE



101: 40"x26"x16"



151: 50"x30"x18"



111: 32"x32"x16"



171: 42"x42"x18"

TABLES DE BOUT



122: 24"x18"x21"



102: 21"x21"x21"



112: 26"x26"x21"

CONSOLES



108: 30"x12"x30"



103: 40"x14"x30"



153: 50"x20"x30"

DÎNER



TABLE
501: 60"x40"x30"



TABLE
511: 72"x40"x30"



CHAISE
706: 17"x20"x42"



BANC
707: 48"x14"x18"

MEUBLES TV



54: 54"x19"x25"



62: 62"x19"x25"

AUTRES



GIGOGNES
104: 28"x15"x25"



BUFFET
603: 48"x14"x36"